

Launching a Melges:

To launch a Melges, you need access to Trondhjems Seilforenings facilities. As of today (18.12.23), we do not have a dedicated card but are working on it:

Door code: 1895

Innermost to the right

Safe straight to the left

Take out the remote control, battery, and protective cover

Boat under the crane

Attach the lifting straps by doubling the strap under the steel pins (one on each side of the keel) then threading it into itself

Insert the keel crane and attach the lifting hook to the ring

Raise the keel completely so it does not rest on the trailer

Prepare the boat crane

Code: 1814

Switch pointing to 0

Pull out the red button on the back of the control

Bottom-left button, crane makes a click

Boat hook in lifting straps. Each side of the keel crane (ensure the boom is on the outside of the straps)

Rope from stern to crane hook

Tighten so that the boat hook is approximately above the keel crane

Tack rope to control the bow

Lift the boat slowly and check the balance point

Lift the boat, move the trailer back, and place the boat in the water

High tide:

Lower the keel and attach the rudder

Low tide:

Move to the dock on the left

Lower the keel and attach the rudder

Remove lifting straps and stern rope and place them in the boat

The plate on the keel

Follow the instructions from "*Rigging and De-rigging Guidelines for Melges 24 on the Water.*", found on the «Documents» page on our website.